

Audi A6


Current Flow Diagram

No. 56

2,5 litre turbo-diesel engine (110kW, 6-cylinder), engine codes AFB, AKN

Model year 1999

Fuse box




Fuse colours:

- 30 A - green
- 25 A - white
- 20 A - yellow
- 15 A - blue
- 10 A - red
- 7,5 A - brown
- 5 A - beige

From fuse number 23 upwards the fuses in the fuse box are designated as 223 etc. in the Current Flow Diagram.


13-point relay carrier



Position of relays:

- 4 - Starter inhibitor relay (J207)
- 6 - Fuel pump relay (J17)

Micro-central electrics



Position of relays:


- 4 - Relay for glow plugs (J52)

Audi A6

Current Flow Diagram

No. 56/1


8-point relay carrier



Position of relays:

- 1** - Radiator fan run-on relay (J138)
- 2** - Radiator fan 2nd speed relay (J101)
- 3** - Radiator fan relay (J26)
- 20** - Radiator fan single fuse (S42)
- 21** - Fuse for radiator fan relay (S142)


3-point relay carrier in electronics box,



Position of relays:

- 3** - Diesel direct injection system relay (J322)
- 5** - Engine control unit fuse (S102)
- 7** - Fuse for glow plugs - engine (S102)
- 9** - Fuse 2 for glow plugs - engine (S125)

Relay carrier, driver's side, behind dash




Position of relays:

- 1** - Low heat output relay (J359)
- 3** - High heat output relay (J360)
- C** - Additional heater fuse 2 (S143)
- D** - Additional heater fuse (S109)


## Audi A6

## Current Flow Diagram

No. 56 / 2




No. 56 / 3



## Audi A6

## Current Flow Diagram

No. 56 / 4




### Diesel direct injection system control unit, air mass meter, injection pump control unit, air mass meter, diesel direct injection system relay

- G70 - Air mass meter
- J248 - Diesel direct injection system control unit
- J322 - Diesel direct injection system relay
- J399 - Injection pump control unit
- N18 - Exhaust gas recirculation valve
- N75 - Charge pressure control solenoid valve
- N144 - Electro/hydraulic engine mounting solenoid valve, left
- N145 - Electro/hydraulic engine mounting solenoid valve, right
- S102 - Engine control unit fuse
- T10n - 10-pin connector, orange, connector point, electronics box, plenum chamber
- 85 - Earth connection -1-, in engine compartment wiring harness
- D101 - Connection -1-, in engine compartment wiring harness
- F25 - Connection -1-, in diesel direct injection system wiring harness
- F26 - Connection -2-, in diesel direct injection system wiring harness

## Audi A6

## Current Flow Diagram

No. 56 / 5




## Diesel direct injection system control unit, cruise control system

- D - Ignition/starter switch
- E45 - Cruise control system switch
- E87 - Control and display unit for air conditioner
- J162 - Heater control unit
- J214 - Thermotronic control unit
- J248 - Diesel direct injection system control unit
- T6z - 6-pin connector, on auxiliary heater control unit
- T10n - 10-pin connector, orange, connector point, electronics box, plenum chamber
- T10q - 10-pin connector, black, on cruise control system switch
- T15e - 15-pin connector, white, connector point, electronics box, plenum chamber
- T15m - 15-pin connector, white, connector point, A pillar, left
- T15 - 15-pin connector, red, connector point, electronics box, plenum chamber
- V54 - Metering pump
- A2 - Positive (+) connection (15), in dash panel wiring harness
- A16 - Connection (cruise control system), in dash panel wiring harness
- L32 - Connection -1-, in heater unit wiring harness
- \* - Models with cruise control system
- \*\* - Models with air conditioner
- \*\*\* - Models with Thermotronic

## Audi A6

## Current Flow Diagram

No. 56 / 6



### Diesel direct injection system control unit, kick-down switch, idling switch, brake light switch, clutch pedal switch, low fuel level sender

- D - Ignition/starter switch
- F - Brake light switch
- F8 - Kick-down switch
- F36 - Clutch pedal switch
- F47 - Cruise control system brake pedal switch (diesel direct injection system)
- F60 - Idling switch
- G79 - Accelerator pedal position sender
- G80 - Needle lift sender
- G210 - Low fuel level sender
- J248 - Diesel direct injection system control unit
- M9 - Brake light bulb, left
- M10 - Brake light bulb, right
- S13 - Fuse in fuse box
- T10n - 10-pin connector, orange, connector point, electronics box, plenum chamber
- T15e - 15-pin connector, white, connector point, electronics box, plenum chamber
- 85 - Earth connection -1-, in engine compartment wiring harness
- A18 - Connection (54), in dash panel wiring harness
- A52 - Positive (+) connection 2 (30), in dash panel wiring harness
- \* - Models with manual gearbox
- \*\* - Models with automatic gearbox 01V


ws = white  
 sw = black  
 ro = red  
 rt = red  
 br = brown  
 gn = green  
 bl = blue  
 gr = grey  
 li = purple  
 vi = purple  
 ge = yellow  
 or = orange  
 rs = pink

97-50341

## Audi A6

## Current Flow Diagram

No. 56 / 7



### Diesel direct injection system control unit, engine speed sender, fuel pump relay

- E87 - Control and display unit for air conditioner
- G28 - Engine speed sender
- G106 - Ambient temperature indicator
- J17 - Fuel pump relay
- J248 - Diesel direct injection system control unit
- N239 - Intake manifold flap change-over valve
- S228 - Fuse in fuse box
- T6a - 6-pin connector, blue, connector point, A pillar, left
- T10c - 10-pin connector, grey, connector point, A pillar, left
- T10n - 10-pin connector, orange, connector point, electronics box, plenum chamber
- T10o - 10-pin connector, brown, connector point, electronics box, plenum chamber
- T10p - 10-pin connector, black, connector point, electronics box, plenum chamber
- T15 - 15-pin connector, red, connector point, electronics box, plenum chamber
- 85 - Earth connection -1-, in engine compartment wiring harness
- A45 - Connection (engine speed signal), in dash panel wiring harness
- A68 - Connection (C15, air conditioner), in dash panel wiring harness
- A73 - Connection (ambient temperature display), in dash panel wiring harness
- A108 - Connection (speed signal), in dash panel wiring harness
- \* - Models with manual gearbox
- \*\* - Models with automatic gearbox 01V
- \*\*\* - Models with air conditioner
- \*\*\*\* - Models with Thermotronic






## Audi A6

## Current Flow Diagram

No. 56 / 9



## Relay and glow plugs for additional heater


- J359 - Low heat output relay
- J360 - High heat output relay
- K - Diagnosis connection
- S109 - Additional heater fuse
- S143 - Additional heater fuse 2
- T10c - 10-pin connector, grey, connector point, A pillar, left
- T10n - 10-pin connector, orange, connector point, electronics box, plenum chamber
- T15u - 15-pin connector, red, connector point, electronics box, plenum chamber
- T16a - 16-pin connector, diagnosis connection
- Z35 - Additional heating heater element
- 44 - Earth point, lower part of left A-pillar
- 156 - Earth connection, in diesel direct injection wiring harness
- A32 - Positive (+) connection (30), in dash panel wiring harness
- A76 - Connection (diagnosis wire K), in dash panel wiring harness
- A99 - Connection -1- (87), in dash panel wiring harness
- F32 - Connection (additional heater), in diesel direct injection system wiring harness
- \* - Models with cruise control system
- \*\* - Does not models with auxiliary heater

97-50344

## Audi A6

## Current Flow Diagram

No. 56 / 10


**Engine cooling**

- E87 - Control and display unit for air conditioner
- F18 - Radiator fan thermo-switch
- F54 - Radiator fan thermo-switch
- F129 - Air conditioner pressure switch
- J26 - Radiator fan relay
- J101 - Radiator fan 2nd speed relay
- J138 - Radiator fan run-on control unit
- N39 - Radiator fan series resistor
- S42 - Radiator fan single fuse
- S142 - Radiator fan control unit fuse
- T10c - 10-pin connector, grey, connector point, A pillar, left
- V7 - Radiator fan
- 44 - Earth point, lower part of left A-pillar
- 193 - Earth connection -1-, in coolant fan wiring harness
- \* - Models with air conditioner

## Audi A6

## Current Flow Diagram

No. 56 / 11



## Dash panel insert, fuel pump, fuel gauge, rev. counter, oil temperature gauge, speedometer, warning lamp

- F1 - Oil pressure switch
- F66 - Coolant shortage indicator switch
- G - Fuel gauge sender
- G1 - Fuel gauge
- G3 - Coolant temperature gauge
- G5 - Rev. counter
- G6 - Fuel pump (pre-supply pump)
- G8 - Oil temperature sender
- G9 - Oil temperature gauge
- G21 - Speedometer
- G22 - Speedometer sender (Hall sender, on gearbox)
- J218 - Combi-processor in dash panel insert
- K2 - Alternator warning lamp
- K3 - Oil pressure warning lamp
- K16 - Reserve fuel warning lamp
- K28 - Coolant temperature/coolant shortage warning lamp
- K29 - Glow period warning lamp
- T10f - 10-pin connector, brown, connector point, A pillar, left
- T10p - 10-pin connector, black, connector point, electronics box, plenum chamber
- T32 - 32-pin connector, blue, on dash panel insert
- T32a - 32-pin connector, green, on dash panel insert
- 85 - Earth connection -1-, in engine compartment wiring harness
- 86 - Earth connection -1-, in rear wiring harness
- 135 - Earth connection -2-, in dash panel wiring harness
- 199 - Earth connection -3-, in dash panel wiring harness
- 269 - Earth connection (sender earth) -1-, in dash panel wiring harness
- \* - Both possible