

Pin assignment at refrigerant pressure/temperature sender - G395-

Contact 1: Earth

Contact 2: Signal output (via air conditioner data bus system "Lin bus" to operating and display unit, Climatronic control unit -J255-)

Contact 3: Positive (terminal "75")



Note

- ◆ With connector -A- unplugged, compressor (air conditioning system compressor regulating valve -N280-) is not actuated.
- ◆ The refrigerant pressure/temperature sender -G395--B- is an electronic control unit.

