

Removing and installing rear parking aid warning buzzer -H15- on belt guide (left-side) - Saloon up to model year 2006

Removing

- Switch off ignition and take out ignition key.
- Remove C-pillar trim →Rep. gr.70.
- Pull rear parking aid warning buzzer - H15--item 3- out of belt guide (left-side) -1- in direction of -arrow-.
- Unplug electrical connector -2-.

Installing

Installation is carried out in the reverse order; note the following:

- Install C-pillar trim →Rep. gr.70.

