

Removing and installing number plate light -X

-

Removing

- Turn light switch to position “0”.
- Unscrew bolt -arrow- in handle trim.



Note

The illustration shows only the number plate light (right-side).

- Lever bulb carrier out of handle trim.
- Take bulb (12 V, 5 W) out of bulb holder.

Installing

Install in reverse order.

